

ISTRUZIONI PER PICCOLE RIPARAZIONI SUI TUBOLARI IN PVC

1. LE PARTI DA INCOLLARE DEVONO ESSERE ACCURATAMENTE LAVATE CON IL CLEANER 264 IN DOTAZIONE NEL KIT
2. AGGIUNGERE ALL'ADESIVO L'ATTIVATORE INSERITO NEL KIT NELLA MISURA DEL 8-10% E MISCELARE IL TUTTO OMOGENEAMENTE. LA MISCELA ADESIVO-ATTIVATORE HA UNA VITA BREVE MAX. 10 MINUTI PER TANTO VA USATA NEL TEMPO INDICATO
3. SPALMARE LA MISCELA ADESIVA SULLE SUPERFICI DA INCOLLARE ATTENDERE 20 MINUTI QUINDI DARE UNA SECONDA MANO
4. TRASCORSI 10 MINUTI DALLA SECONDA MANO RIATTIVARE L'ADESIVO CON UN SOFFIONE DI ARIA CALDA, OPPURE CON UNA LAMPADA A RAGGI INFRAROSSI FINO A QUANDO L'ADESIVO SPALMATO SO INTIEPIDISCE. UNIRE LE DUE SUPERFICI ANCORA TIEPIDE QUINDI PRESSARE IMMEDIATAMENTE MEGLIO CON UN PEZZO DI LEGNO SAGOMATO
5. L'INCOLLAGGIO FINALE SI OTTIENE DOPO LE 72 ORE

USING ISTRUCTION FOR SMALL REPAIR ON PVC RUBBER BOAT

1. BOTH SIDES HAVE TO BE CAREFULLY CLEANED WITH CLEANER 264 CONTAINING IN THIS KIT
2. ADD 8-10% OF "ATTIVATORE" TO THE GLUE AND MIX CAREFULLY. THIS MIXTURE IS GOOD FOR 10 MINUTES MAXIMUM.... USE IT IN TIME
3. SPREAD THE MIXTURE ON BOTH SIDES AND WAIT FOR ABOUT 20 MINUTES AND THEN SPREAD THEM ANOTHER HAND
4. AFTER 15 MINUTES BLOW THE TWO SIDES WITH WARM AIR OR WARM THEM WITH INFRA-RED RAY. PUT THEM TOGETHER AND PRESS CAREFULLY WITH SHAPED PIECE OF WOOD
5. WORK WILL BE COMPLETED IN 72 HOURS

OSCOLATI SPA
VIA PACINOTTI NR. 12
20090 SEGRATE